

L03 and L05 Intake Modifications

“Caddy” Intake -



This method uses the stock air box and stud from a throttle body injected Cadillac along with a length of PVC and a cone filter. The air box must be modified to accept the Intake Air Temperature sensor.

“Caddy” Intake with RAISS -



Dual Snorkel on Stock Intake -



This involves obtaining a stock intake snorkel from a parts car and modifying the air box to accept a second intake tube.